

...Protecting What Matters Most.

SWIPC



# **Operating Instructions**

Thank you for choosing this product. Before operating, please read all instructions completely and keep for future reference.

#### Software Installation

- 1) For Apple: Download YooSee from the App Store.
- 2) For Android: Download YooSee from the Google Play Store

Data usage may apply.

## 2. Account Registration

Note: You must create an account and register your device before operating.



- 1) Click "Registration" on the right-hand side.
- 2) Select either "Mobile Registration" or "Email Registration." then click Next.
- Enter your email address and password, then click next. If you are registering by email, there is no verification code needed for registration. If registering by mobile, a text message will be sent containing the verification code needed.
- 4) A window will appear notifying you once you have successfully registered. The system will automatically assign you an ID. Please remember the ID as this will be your username. Click OK and enter the password again, which will log you into the YooSee App.



## 3. ONLINE CONNECTION

- Plug-Camera into outlet using the included power cord. You will also connect an Ethernet cable (not included) into the camera and into your wireless router.
- Once camera is plugged in, it will self-test by moving in all directions. Once the camera has stopped performing this function, you may begin adding the camera to the APP.
- On the device list screen, press the "+" symbol. This will give you the ability to add the camera via smartlink or manual connection. Choose MANUAL CONNECTION.
- Enter the camera's credentials as requested. The Camera ID and temporary password is located on the bottom of your camera.

# 4. WI-FI CONNECTIVITY

- After following all steps listed above, you should see the camera listed on the "device list" screen in the APP. You should also notice that the camera listed states. "online."
- 2) Click on "settings" for IOS or "set" if you are using Android.
- Click on Network Settings
- 4) Choose the "wireless connectivity" option.
- 5) Choose which wi-fi network you wish to use. Please keep in mind that if you have more than one network, choose the network which will be closest to the cameras final placement in your home or office.

- Enter YOUR wifi router password.
- Once connected, remove Ethernet cable (not included). You
  may unplug the power cord and move the camera to its final
  place.
- 8) After plugging the camera in at its final place remember the camera will self test going through all movements of operation. Once this movement has stopped (10 seconds) the camera will connect wirelessly giving you full operation of the camera.

## 5. Real-Time Monitoring

On the "Device List" page, select the device you would like to use and you will enter Real-Time mode.

### 6. Recording Setup

- 1) Recording: This camera supports a maximum 64GB microSD card for recording storage. To record, insert the microSD card first, then enable the YooSee App. Click "Device List", then select your device. Then Settings, and select "Recording Setting." Manual and Alarm Recording options are also available.
- 2) Playback: This camera supports playback on mobile phones. To begin playback, open the YooSee App, navigate to the Devices page, and select your device. You will then select Playback and choose the file that you would like to view.

# 7. Zone Settings

1) Pairing Detectors:

Note: This feature is optional; please verify your device is capable before attempting.

The SWIPCPT supports pairing with 8 remote controls, 8x8=64 wireless detectors (433 Hz).

A. Add devices to the "Device List" in the YooSee App. B. Click "Device List", then Device Name, then Settings, and Zone Settings. C. For example, to pair a door sensor installed in the hall, code as 1. First click "Hall" button and select "1." A window will pop-up; select "OK" to set the sensor. When the door is opened, the sensor will be triggered. If the match is successful, you will be notified and the gray number will change to blue.

D. Navigate back to the device list and click the lock icon beside the device to arm. The detector will be active 10 seconds after the detector has been armed. E. Follow the same steps listed as A, B, and C. The function is the same as the lock icon as described in D. It can be used for arming and disarming, but will need to be programed to match the device.

2) Deleting Paired Detectors

Select the paired detector and confirm the deletion.

3) Alarm Settings

There are two methods to arm the device. The first method is to press the Lock key on the infrared remote control that has been paired. The second method is to select the Lock icon in the YooSee App contact list. When the alarm is triggered, the device will send a n app alert and captured images to the registered account(s) simultaneously.

To set an account to receive the images, select the device in the app, then select "Settings", and "Alarm Settings." Enter the app ID you would like to receive the alerts and images. You can use up to five accounts to receive said alerts.



The alarm will sound as soon as motion has been detected. The buzzer will sound until the device has been disarmed.

## 8. Updating Your Device

Select the device on the Devices page in the YooSee app and navigate to Settings>Check for Updates. If an update is available, select the update, and follow the on-screen prompts.

## 9. Warranty

- 1. Streetwise Security Products extends a one year warranty for defects in materials or workmanship, with the following exceptions:
- A. The warranty does not cover damage resulting from accident, misuse or abuse, lack of reasonable care, moisture, the affixing of any attachment not provided with the product, loss of parts, or recharging the unit in any manner not in accordance with the included instructions
- B. The warranty will be voided if the unit has been opened or tampered with in any way (unless by an authorized dealer) or if any unauthorized replacement parts have been used.
- Conditions of Sale: Purchase of this product is an agreement by the purchaser/user to hold all sellers and manufacturers harmless of all liabilities and damages.
- 3. To Obtain Service: Contact the Authorized Dealer from whom you purchased this unit for a Return Merchandise Authorization. The return unit must be sent postage prepaid and proof of purchase is required. Damage or loss occurring during shipment is not covered by this warranty.

2 3 <u>Revised 03-03-2016</u>